

Hydrokompenser Option for SBS Balancer Control

L-4300-2



OPERATION AND SPECIFICATION MANUAL ADDENDUM

Schmitt Industries, Inc.

2765 N W Nicolai ■ Street Portland, OR 97210 USA
Phone: 503-227-7908 ■ Fax: 503-223-1258
<http://www.schmitt-ind.com>



Limited Use License Agreement

YOU SHOULD CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE OPENING THE PACKAGE CONTAINING THE COMPUTER SOFTWARE AND HARDWARE LICENSED HEREUNDER. CONNECTING POWER TO THE MICROPROCESSOR CONTROL UNIT INDICATES YOUR ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT AGREE WITH THEM, YOU SHOULD PROMPTLY RETURN THE UNIT WITH POWER SEAL INTACT TO THE PERSON FROM WHOM IT WAS PURCHASED WITHIN FIFTEEN DAYS FROM DATE OF PURCHASE AND YOUR MONEY WILL BE REFUNDED BY THAT PERSON. IF THE PERSON FROM WHOM YOU PURCHASED THIS PRODUCT FAILS TO REFUND YOUR MONEY, CONTACT SCHMITT INDUSTRIES INCORPORATED IMMEDIATELY AT THE ADDRESS SET OUT BELOW.

Schmitt Industries Incorporated provides the hardware and computer software program contained in the microprocessor control unit, and licenses the use of the product to you. You assume responsibility for the selection of the product suited to achieve your intended results, and for the installation, use and results obtained. Upon initial usage of the product your purchase price shall be considered a nonrefundable license fee unless prior written waivers are obtained from Schmitt Industries Incorporated.

LICENSE

- a. You are granted a personal, nontransferable and non-exclusive license to use the hardware and software in this Agreement. Title and ownership of the hardware and software and documentation remain in Schmitt Industries, Incorporated;
- b. the hardware and software may be used by you only on a single installation;
- c. you and your employees and agents are required to protect the confidentiality of the hardware and software. You may not distribute, disclose, or otherwise make the hardware and software or documentation available to any third party;
- d. you may not copy or reproduce the hardware and software or documentation for any purpose;
- e. you may not assign or transfer the hardware and software or this license to any other person without the express prior written consent of Schmitt Industries Incorporated;
- f. you acknowledge that you are receiving only a LIMITED LICENSE TO USE the hardware and software and related documentation and that Schmitt Industries Incorporated retains title to the hardware and software and documentation. You acknowledge that Schmitt Industries Incorporated has a valuable proprietary interest in the hardware and software and documentation.

YOU MAY NOT USE, COPY, MODIFY, OR TRANSFER THE HARDWARE AND SOFTWARE, IN WHOLE OR IN ANY PART, WITHOUT THE PRIOR WRITTEN CONSENT OF SCHMITT INDUSTRIES, INCORPORATED.

IF YOU TRANSFER POSSESSION OF ANY PORTION OF THE HARDWARE OR SOFTWARE TO ANOTHER PARTY, YOUR LICENSE IS AUTOMATICALLY TERMINATED.

TERM

The license is effective until terminated. You may terminate it at any other time by returning all hardware and software together with all copies of associated documentation. It will also terminate upon conditions set forth elsewhere in this Agreement or if you fail to comply with any term or condition of this Agreement. You agree upon such termination to return the hardware and software together with all copies of associated documentation. In the event of termination the obligation of confidentiality shall survive.

12 MONTH LIMITED WARRANTY

EXCEPT AS STATED BELOW IN THIS SECTION THIS PRODUCT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Schmitt Industries Incorporated does not warrant that the functions contained in the product will meet your requirements or that the operation of the product will be uninterrupted or error free.

Schmitt Industries Incorporated does warrant as the only warranty provided to you, that the product which is furnished to you, will be free from defects in materials and workmanship under normal use for a period of twelve (12) months from the date of delivery to you as evidenced by a copy of your warrant receipt.

LIMITATIONS OF REMEDIES

Schmitt Industries Incorporated's entire liability and your exclusive remedy shall be:

1. the replacement of any hardware and software not meeting Schmitt Industries' "Limited Warranty" and which is returned to Schmitt Industries Incorporated or an authorized Schmitt Industries dealer with a copy of your purchase receipt, or
2. if Schmitt Industries Incorporated or the dealer is unable within ninety (90) days to deliver a replacement product which is free of defects in material or workmanship, you may terminate this Agreement by returning the product and your money will be refunded to you by the dealer from whom you purchased the product.

IN NO EVENT WILL SCHMITT INDUSTRIES INCORPORATED BE LIABLE TO YOU FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE SUCH PRODUCTS EVEN IF SCHMITT INDUSTRIES INCORPORATED OR AN AUTHORIZED DEALER HAD BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

SOME AREAS DO NOT ALLOW THE LIMITATIONS OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

GENERAL

You may not sublicense, assign or transfer the license or the hardware, software, and documentation except as expressly provided in this Agreement. Any attempt otherwise to sublicense, assign or transfer any of the rights, duties or obligations hereunder is void.

This Agreement will be governed by the laws of the United States and the State of Oregon, United States of America.

Should you have any questions concerning this Agreement, you may contact Schmitt Industries Incorporated by writing to:

Schmitt Industries Incorporated
2765 NW Nicolai St.
Portland, Oregon 97209 USA

YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS. YOU FURTHER AGREE THAT IT IS THE COMPLETE AND EXCLUSIVE STATEMENT OF THE AGREEMENT BETWEEN YOU AND SCHMITT INDUSTRIES INCORPORATED AND ITS DEALER ("US") WHICH SUPERSEDED ANY PROPOSAL OR PRIOR AGREEMENT, ORAL OR WRITTEN, AND ANY OTHER COMMUNICATIONS BETWEEN US RELATING TO THE SUBJECT MATTER OF THIS AGREEMENT.

Operation and Specification Addendum for the **SBS** **Hydrokompenser Option**

Manual addendum for use with the
SBS Balance System Operation Manual (Document L-4100-x)

Part# L-4300-2

Revision # 2.0

© 1998 **Schmitt Industries, Inc.**
2765 NW Nicolai St.
Portland, OR 97210 USA
Tel.: +1-503-227-7908
Fax: +1-503-223-1258
www.schmitt-ind.com
e-mail: bal-sales@schmitt-ind.com

Schmitt Europe Ltd.
University of Warwick
Science Park Ltd., Sir William Lyons Rd.
Coventry, CV4 7EZ, England
Tel.: +44-1203-597192
Fax: +44-1203-412697
e-mail: bal-uk@schmitt-ind.com

Table of Contents

Product Overview	1
System Configuration.....	1
System Installation	3
System Connections	3
Valve Block Installation	4
Nozzle Block Installation and Alignment.....	4
Calibrating the Speed Sensor	4
Setting Wheel Rotation Direction.....	5
Operating Instructions	5
Displayed Error Messages	6
Troubleshooting	11
Appendix A: Replacement Parts List	12
Appendix B: System Component Overview	13
Appendix C: Valve Block Mounting	14

Product Overview

This manual addendum describes the installation and use of SBS Hydrokompenser fluid balancers. Only issues particular to the Hydrokompenser system are discussed, including System configuration and installation. Operation of SBS Hydrokompenser balancers is similar to mechanical balancers, and the user is directed to refer to the SBS Balance System Operation and Specification Manual (L-4100-1) for complete details on system operation.

System Configuration

The balancing system consists of:

- **The SB-4500 Series measuring and control unit**
- **A piezoelectric vibration sensor with integrated charge amplifier**
- **An annular container (the “balancing chamber” for the liquid correction medium)**
- **An injection system (the “Nozzle Block”)**
- **A valve block with integrated coolant conditioning unit**

All components of the balancing system are microprocessor-controlled. Should performance fail, the diagnostic system will signal the cause. Important machine parameters such as balance tolerance, balance quality, smooth running of the grinder and speed are available through the information system. Control of the balancing operation is either manual or automatic via the machine controller. Figure 1 explains the basic operation of the Hydrokompenser system using four quadrants inside the balancing chamber. The reference numbers in the following text refer to Figure 2 showing a schematic system overview.

Compensation of grinding wheel unbalance (U) is by means of liquid media (coolant or oil). The liquid medium is injected into the annular container (8), which is secured to the rotating grinding wheel flange (1). The compensation weight (K) is subdivided into two vectors ($V1 + V2$).

A vibration transducer (3) is fitted on the headstock for determination of the amount of unbalance, while the speed sensor usually built into the nozzle block (4) detects the position of unbalance. (External speed sensors are also available.) The correction weight is determined by the electronic measuring and control unit (5) to control mass correction ($V1 + V2$) accordingly. Hence the individual valves in the valve block (7) open as commanded by the control unit and the liquid medium (machine coolant 6) is led to the corresponding nozzle in the nozzle block (4). The nozzles inject the coolant into one or two quadrants in the ring chamber (8) as a continuous stream. The annular grooves collect the liquid and insure most of it enters the required quadrant.




Fig.1 Vector diagram of unbalance (U), compensation weight (K) and Vectors $V1$ and $V2$ of fluid in chambers

The SBS Hydrokompenser controller unit is essentially the same as the SB-4500 controller for mechanical systems. To differentiate the systems, it carries a -H suffix on the part number. An acoustical emission card (AEMS) together with the corresponding sensor can be added to the controller if required. The AEMS sensor is a high frequency acoustical sensor, designed for use with the SBS AEMS product. This

product can be ordered separately and enables the user to monitor the grinding process on the machine, providing Gap Elimination, Crash protection, and dressing and grinding monitoring.




Fig 2. Schematic diagram of SB-4500-H Hydrokompenser System

The Hydrokompenser System allows for a great variety of implementation, and supports machine operation at machine speeds up to 15,000 rpm in certain applications, which makes it the perfect solution for solving unbalance problems on machine types that mechanical balancers can't address. Individual Hydrokompenser Chambers are designed for individual applications, with specific maximum spindle rotational speeds for each design. **Caution: Exceeding the maximum spindle speed reported to Schmitt Industries, Inc. during application engineering, may result in dangerous part failure.**

A chamber can be designed for any application, and can be bolted to the grinder (Fig. 3), or be built into the machine for OEM applications (Fig. 4). This manual addendum can therefore not possibly cover all methods of attachment of chambers to machines. However, they all have in common a simple installation by several bolts and a pilot bore for precise alignment.




Fig 3




Fig. 4

System Installation

System Connections

To operate the SBS Hydrokompenser, it is necessary to have a Hydrokompenser version Balance Control Card installed in your SBS Control Unit. If your control unit model is designated with a -H suffix, then this type of control card was shipped with your unit. The required card (P/N SB-4518) can also be ordered separately and installed into any SBS 4500 series control. To add cards to the SBS control unit, follow the Balancer Card installation instructions in the SBS System Operation Manual.

In one of the numbered slots on the rear of the control unit, locate the Hydrokompenser you wish to connect to. This card will look like the picture at right, with the top connector having twelve pins. Use the supplied SB-46xx series cable to connect the Valve Block to the Control unit. Vibration Sensor installation and location is covered in depth in the system Operation Manual. Care must be taken to locate the Sensor properly on the machine.




Fig. 5

Refer to the overview drawing in Appendix A for a better understanding of the necessary cable connections and all possible cable lengths and variations.

Valve Block Installation

Other than cable connections, the other issue particular the Hydrokompenser Balancers is the installation of the Valve Block in a clean part of the machine as close as possible to the nozzle block. Typically, the valve block is mounted at a distance of 1,5 meters (5 feet). This corresponds to the standard length of hose attached to the nozzle blocks. The mounting dimensions for the valve block can be found in Appendix B.

Nozzle Block Installation and Alignment

This separate unit must be mounted to a stationary part of the machine, located so that the outer face of the cylindrical portion of the “round” nozzle block, or the nozzle tip of the “L-shaped” flat nozzle block is facing directly opposite the Chambers on the Balancer. The alignment of the nozzles is critical, as it determines the speed and accuracy of the balancing process. For proper operation, the nozzles must be located within a maximum distance from the Chamber face of 1-3 mm.

Attachment to the machine is best accomplished by a simple bracket of proper dimension to hold the Nozzle Block in the required position during machine operation. Where necessary, the ability to make finish adjustments in distance and alignment of the Sender should be provided for in the bracket design. Because the requirements for mounting are dependent on individual machine design, machine use, and customer preference, the customer should provide the required bracket for attachment of the Sender. SBS will provide design and fabrication services for customers who so desire.

Once the nozzle block is hooked up properly to the valve block, set the pressure using the pressure regulator on the valve block. Adjust the coolant jet exiting the nozzles in a way that it is deflected after 1 ½ ft. (0.5 m). If a water-based coolant is used, this should correspond to a pressure of 7 - 21 psi (0.5-1.5 bars), depending on the distance between valve block and nozzle block. If oil is used, this should correspond to a pressure of 14 – 58 psi (1-4 bars).

Calibrating the Speed Sensor

The speed sensor can be automatically calibrated the first time the unit is operated. After installation of all system components and cables, switch on the controller and wait for it to display the main menu. Do not switch on the spindle. Loosen the mounting bolts and shift the speed sensor or the Nozzle Block, so that it touches the metal of the mating face on the part that normally rotates (spindle or chamber). Then pull the speed sensor or Nozzle Block back to the specified gap of 1 to 3 mm. The system should have recognized and calibrated the speed sensor. If this is not the case, chose “RPM SENSOR” from the MENU. A graphics appears depicting the gap between speed sensor and chamber or spindle. Shift the speed sensor so that the graphic shows the correct distance.




Fig. 6 Round Nozzle Block with standard mounting bracket and hose attached

Setting Wheel Rotation Direction

This separate unit must be mounted to a stationary part of the machine, located so that the outer face of the cylindrical portion of the “round” nozzle block, or the nozzle tip of the “L-shaped” flat nozzle block is

Chose the “DIRECTION” option from the MENU. This is specific to the Hydrokompenser. A menu appears, called “WHEEL ROTATION AND CHAMBER DIRECTION”. There is a choice of four menu items

1. AUTOMATIC ALWAYS – Every balance operation, the direction will be determined automatically by trial injections into all four chambers. This can be useful when the spindle swivels or otherwise changes direction.
2. AUTOMATIC ONCE – On the first balance cycle after selecting this option, the system will automatically determine the direction by performing trial injections into all four chambers. The result is stored and the auto-determination cycle is not run again.
3. SAME – This setting allows the operator to manually input the direction as SAME, without running the auto-determination cycle.
4. OPPOSITE – This allows the operator to manually input the direction as OPPOSITE, without running the auto-determination cycle. It is best to try either SAME or OPPOSITE and see which of the settings works best.

Operating Instructions

Hydrokompenser balancer operation is identical to standard mechanical systems. See SBS Operation and Specification Manual (L-4100-1) for details. There are only a few minor differences in the menus:

Whereas mechanical balancer manual operation buttons are designated M1, M2, M3, M4; indicating “Motor”, the Hydrokompenser manual operation buttons are designated C1, C2, C3, C4, indicating “Chamber”: Pressing these buttons activates the solenoid of the respective injection nozzle. This allows the operator to inject as much liquid as he wishes into each one of the chamber. This is typically used for diagnostic purposes. See the chapter on “Manual Balancing” in the SBS Operation and Specification Manual (L-4100-1) for details.

Displayed Error Messages

New self-diagnostic software has been incorporated into all SBS Balance Control Units. If a problem ever occurs with an SBS system, It is quickly reported on the front panel display in the form of an error code. Below is a listing of these codes, a description of when the Control Unit automatically runs each test, how each code is cleared, the definition of each error message, as well as the prescribed action to be taken by the user of the system. To further isolate defective components a series of test operations accompany some of the error codes. The following list is that of ALL error messages that appear with the Hydrokompenser system. Some of them are identical to error messages for mechanical balancers.

A— Checked continuously.....

message: **RPM OUT OF RANGE**
OPERATION RANGE IS
300-30000
CHECK RPM SENSOR

Clears automatically.

definition: Displayed if the RPM signal coming from the Speed Sensor is below 300 RPM or exceeds 30,000 RPM and the RPM number cannot be displayed.

action: Verify operating speed of the grinding machine. If the machine is running above 30,000 RPM, contact your SBS Balance System source for application consultation. If the machine is running within the operating speed limits, and this error message persists, this indicates a failure of the Speed Sensor in the Nozzle Block. The Nozzle Block should be returned for service, or the Speed Sensor replaced.

B— Checked Continuously.....

message: **VIB SENSOR DEFECT**
SHORT – CHECK CABLE
AND CONNECTORS -
SEE MANUAL

Clears automatically.

definition: Vibration Sensor presence not detected. This could be caused by a defective sensor or by no sensor being connected.

action: Check sensor connections and try Power-On again. Continued error messages indicate the need for repairs to the Sensor.

C— Checked Continuously.....

message: **VIB SENSOR DEFECT**
SHORT – CHECK CABLE
AND CONNECTORS –
SEE MANUAL

Clears automatically.

definition: Vibration sensor short circuit detected.

action: Disconnect the balancer from AC power before checking cables and connectors, and sensor for shorts. If the problem can not be isolated, the sensor, cable, and/or Control Unit should be returned for repair.

D— Checked at the end of a motor pulse

message: **VALVE DRIVER FAULT**
SHORT – CHECK CABLE
AND CONNECTORS –
SEE MANUAL

Cleared manually.

definition: Solenoid – short circuit detected.

action: Determine which is the defective component by swapping with another system, or by using the following diagnostic test. Return defective component for repairs. If in doubt, return all items.

test: Shut off the grinding spindle, and disconnect the Balance Head Cable from the Valve Block, but not from the Control Unit. Press MAN. Button on control to enter manual control mode. Press and hold down the first of the four manual C buttons for 15 seconds. Repeat with each of the manual C buttons (only one button can be actuated at a time).

If error E is displayed, clear this error, as it is expected. If no other error occurs during this test, then the problem is with the Valve Block. If error D or F is displayed, then continue on and perform part two of this test.

Disconnect the cable from the Control Unit, and repeat the above test, using all four manual C buttons. If error E is displayed, clear this error, as it is expected. If no other error occurs during this test, then the problem is with the Valve Block Cable. If error D or F is displayed, the problem is with the Control Unit.

E— Checked at the end of a motor pulse

message: **VALVE DRIVER FAULT**
OPEN – CHECK CABLE
AND CONNECTORS –
SEE MANUAL

Cleared manually.

definition: Solenoid – open circuit detected.

action: Determine which is the defective component by swapping with another system. Return defective component for repairs. If in doubt, return all items.

F— Checked at the end of a solenoid pulse

message: **VALVE DRIVER FAULT**
EXCESS CURRENT -
PERFORM MANUAL
FUNCTION TEST

Cleared manually.

Cleared by pressing Auto button.

definition: Solenoid – excessive current detected (short or stall).

action: Verify that both ends of the Balance Head Cable are properly attached. If connector pins are contaminated, clean with electrical contact cleaner. If problem persists, determine if the Valve Block Cable is the defective component by swapping with another system, or by using a voltmeter, and the enclosed Balance Head Cable Schematic in the L-4100-1 manual. Return defective cable or Valve Block for repairs. If in doubt, return both items.

G— Checked continuously.....

message: **AUX POWER DEFECT**
SHORT – CHECK CABLE
AND CONNECTORS -
SEE MANUAL

Clears automatically.

definition: 24V Auxiliary Supply low – fuse open.

action: Determine which is the defective component by swapping with another system, or by using the following diagnostic test. Return defective component for repairs. If in doubt, return all items.

test: Check for shorts in cables and connectors and re-initiate system check. If the error persists return Control Unit and cables for repair.

H— Checked Continuously.....

message: **RPM/CNC POWER DEFECT**
SHORT – CHECK CABLE
AND CONNECTORS -
SEE MANUAL

Clears automatically.

Cleared by pressing Auto button.

definition: 15V Auxiliary supply low – fuse open.

action: Check for shorts in Head/CNC cables and connectors and re-initiate system check. If the error persists return Control Unit and cables for repair. If you have the SBS system cabled to your CNC controller, verify that the CNC cable is free of electrical shorts. The CNC cable is not supplied with the SBS system, and repair is the responsibility of the user.

I— Checked during Auto Balance cycle.....

message: **AUTO-BALANCE FAILED**
LIMIT NOT REACHABLE
BEST BALANCE
ACHIEVED AT

Cleared manually.

Cleared by pressing Auto button.

definition: Auto Balance Failed – unable to reach limit.

action: Reset the PULSE setting to “CAUTIOUS”, and verify system integrity as OK (*see: Trouble shooting Guide section*). If this error continues, there are two possible causes of this error.

- 1) LIMIT set too Low - The LIMIT must be set 0.2 higher than the Measured background vibration (*see: Other Sources of Vibration section*).
- 2) It is a signal that the Balance Head supplied is sized incorrectly for the application. Conduct the test described in the Verifying Balance Head Size section. If test results are outside suggested levels, contact your SBS Balance System source to discuss replacement.

J— Checked Continuously during Auto-Balance Cycle

message: **NO RPM SIGNAL**
CHECK CABLES
CHECK SPINDLE

Cleared automatically.
Cleared by pressing Auto button.

definition: No incoming RPM signal, possible open in RPM sensor circuit.

action: Ensure that spindle is running, with balancer cable attached at both balancer and control ends. Determine which is the defective component by swapping with another system. Return defective component for repairs. If in doubt, return all items.

K— Checked when Auto Balance Cycle Completed

message: **ABNORMAL CONDITION**
BAL CYCLE COMPLETED
AFTER ERROR DETECTED
SEE MANUAL

Checked when Auto Balance Cycle Completed.

definition: Balance cycle completed after error detected and cancelled, clears automatically.

action: No action required other than clearing manually from the Balancing screen.

L— Checked when Auto Balance Cycle Completed

message: **CIRCUIT FAILURE**
UNABLE TO MEASURE
VIBRATION
SEE MANUAL

definition: Signal acquisition circuit failed.

action: Clears automatically, no action required other than clearing manually from the Balancing screen. If the problem persists, the Control Unit should be returned for repair.

M— Checked Continuously during Auto-Balance Cycle

message: **FILTER CONTAC OPEN**
COOLANT FILTER CLOGGED -
CLEAN OR REPLACE
COOLANT FILTER

definition: Coolant filter indicator indicates clogged filter.

action: Stop Machine, clean or replace filter and restart balancing.

N— Checked when Auto Balance Cycle Completed

message: **CHAMBER FULL**
EMPTY CHAMBER AND
RESTART BALANCING
CHECK INITIAL UNBALANCE

definition: Balancing chambers might be full.

action: Stop Machine Spindle, empty chambers and restart balancing. If problem persists, either chambers are clogged with dirt and capacity is reduced, or unbalance is too big for installed chambers. Clears automatically.

O— Checked Continuously during Auto-Balance Cycle

message: **RPM UNSTABLE**
CHECK SPINDLE
CHECK MACHINE

definition: Unstable reading by RPM sensor.

action: Stop Machine, check setting of speed sensor. Check speed sensor operation, replace if necessary. Clears automatically.

P— Checked Continuously during Auto-Balance Cycle

message: **CHECK DIRECTION SETTING**

definition: Incorrect direction setting.

action: The Hydrokompenser needs a correct direction setting to identify the chamber sequence 1,2,3,4. Check setting. Try different setting, if necessary.

Troubleshooting


Failure	Cause	Remedy
Unbalance increases constantly in short time	Annular container leaks	Seal container
None or little change of unbalance while injecting	Annular container leaks, poor injection	Adjust valve block
	Hydraulic circuit does not operate properly	Check hydraulic as follows: — Select Manual Mode — Change unbalance display by about 1 pm by injecting coolant for example into valve 1 (chamber 1) This procedure takes about 10-20 seconds. When operating valve 3 (chamber 3) the amount of vibration display has to be brought back to the basic initial value in the same time. The same procedure has to be repeated with valves 2 and 4 (chambers 2 and 4). If this cannot be done, the following measures have to be taken: — Check or - if necessary - change connections of valves 1, 2, 3, 4 — Adjust valve block correctly — Place chamber no. 1 opposite to injection valve 1. The liquid jet will not be reflected if positioning is correct. — Adjust coolant pressure in a way that the liquid jets of all valves are deflected after approx. 1 ½ ft (0.5 m).
System cannot be balanced to within tolerance	Interfering vibrations	Balance vibrating assemblies (e.g. drive motor) Change speed of possible second spindle Change position of vibration transducer at same level
	Coolant pressure	Adjust jet in a way that it is deflected after 1 ½ ft. (0.5 m) Water: 7 - 21 psi (0.5-1.5 bars) Oil: 14 – 58 psi (1-4 bars)
	Hydraulic circuit does not operate properly	See above
	Vibration transducer is placed at a bad spot	Fit vibration transducer in another position of machine
	Tolerance limit too low	Increase tolerance limit

Appendix A: Replacement Parts List


<u>Part#</u>	<u>Description</u>
<u>Balancer Cables¹</u>	
SB-46xx	Valve Block Cable /SB-4500 series
<u>Controls/ Options</u>	
SB-43xx	Remote Keypad Cable for SB-4400
SB-24xx-L	CNC cable (standard lengths)
SB-4500-H	CONTROL UNIT Hydrokompenser (Expandable to 4 Channels)
SB-4400-H	CONTROL UNIT Hydrokompenser (Expandable to 2 Channels)
SB-4450	Remote Keypad (option for SB-4400)
SB-43xx	Remote Keypad connection cable (option for SB-4400)
SB-4475-H	CONTROL UNIT (w/ optional installed front panel)(Expandable to 2 Channels)
SB-4518	Additional Hydrokompenser (water balancer) Channel Card
SB-4522	AEMS Gap/Crash Monitoring System Card
<u>Vibration Sensors¹</u>	
SB-14xx	Sensor Cable (standard lengths)
SB-16xx	Sensor Ext. Cable (standard lengths)
<u>Control Mounting Hardware Options</u>	
SB-0451	Rack Mount Panel: SB-4500 – 19”
SB-0441	Rack Mount Panel: SB-4400 ½ Rack DIN 3U
MC-0400	Control Mount Bracket: SB-4500
SB-0442	Control Mount Bracket: SB-4400
<u>Other Parts²</u>	
EC-5605	Control Unit Fuse, 3 amp slow-blo 5x20 (2 required)
CA-0009	Power Cordset
CA-0009-G	Power Cordset (Germany)
CA-0009-B	Power Cordset (British)
SH-4000	Complete Valve Block with Filter, Pressure regulator, Pressure Indicator and Clog Indicator
SH-1778	External Speed Sensor
SH-1779	Extension Cable for External Speed Sensor
CA-0121	12-pin Male DIN (control end plug of Balancer Cable for 46xx series cables)

- 1) xx = cable length in feet - standard options 11, 20, or 40 at standard price
- 2) Note that Nozzle Blocks and Ring Chambers are machine-specific parts. Please contact your Schmitt Representative for details.

Appendix B: System Component Overview



Appendix C: Valve Block Mounting



Dimensions in Millimeters